



From PL1402-SC-T42

to



U402-SC-T42-SM

TOOLS REQUIRED FOR FLUSH VALVE INSTALLATION:

- A) Straight Blade Screwdriver
- B) Allen Key
- C) Flat-jawed Adjustable Pipe Wrench.
(Recommended: E110 by Rigid)

WARNING: Never use any tools with teeth

Retro-Fit Steps

- 1) Turn water off at the Control Stop
- 2) Press Override Button on top of head to relieve pressure in solenoid
- 3) Remove Pulsar head by loosening sets screws with allen key
- 4) Remove metal cover with flat-jawed wrench
- 5) Insert the Tilting Rod (#20) down the center of diaphragm
- 6) Screw on new Flushboy Ultra valve cover (U160-1.28A)

Attached SideArm unit by following the accompanying instructions.