

Flush Valve Guide for Metcraft Fixtures

CROSS REFERENCE FOR COMBINATION FIXTURES

OLD NUMBER	NEW NUMBER REAR MOUNT	NEW NUMBER FRONT MOUNT
100-90-C-15	3115-90C	N/A
100-45-15 (L) (R)	3115-45 (L) (R)	N/A
100-90-C	3118-90C	3618-90C
100-90-18-OS (L) (R)	3118-90 (L) (R)	3616-90 (L) (R)
100-45 (L) (R)	3118-45 (L) (R)	3618-45 (L) (R)
100-90-20-OS (L) (R)	3120-90 (L) (R)	3620-90 (L) (R)
100-45-20 (L) (R)	3120-45 (L) (R)	3620-45 (L) (R)
100-90-26-OS (L) (R)	3126-90 (L) (R)	3626-90 (L) (R)
100-45-26-OS (L) (R)	3126-45 (L) (R)	3626-45 (L) (R)
100-90-HC (L) (R)	3130-90 (L) (R)	3630-90 (L) (R)
100-45-HC (L) (R)	3130-45 (L) (R)	3630-45 (L) (R)

COMBINATION WATER CLOSET & LAVATORY

FIXTURE NUMBER	SLOAN	DELANY	FIXTURE NUMBER	SLOAN	DELANY
3115-90C	603-1.5	623-1.5	3618-90C	950-1.5-F22 MBFW	1233-1.6-FW
3115-45 (L) (R)	603-1.5	623-1.5	3618-90 (L) (R)	950-1.5-F22 MBFW	1233-1.6-FW
3118-90C	603-1.5	623-1.5	3618-45 (L) (R)	950-1.5-F22 MBFW	1233-1.6-FW
3118-90 (L) (R)	603-1.5	623-1.5	3620-90 (L) (R)	950-1.5-F22 MBFW	1233-1.6-FW
3118-45 (L) (R)	603-1.5	623-1.5	3620-45 (L) (R)	950-1.5-F22 MBFW	1233-1.6-FW
3120-90 (L) (R)	603-1.5	623-1.5	3626-90 (L) (R)	950-1.5-F22 MBFW	1233-1.6-FW
3120-45 (L) (R)	603-1.5	623-1.5	3626-45 (L) (R)	950-1.5-F22 MBFW	1233-1.6-FW
3126-90 (L) (R)	603-1.5	623-1.5	3630-90 (L) (R)	950-1.5-F22 MBFW	1233-1.6-FW
3126-45 (L) (R)	603-1.5	623-1.5	3630-45 (L) (R)	950-1.5-F22 MBFW	1233-1.6-FW
3130-90 (L) (R)	952-1.5MBFW				
3130-45 (L) (R)	952-1.5MBFW				